

CONTROL WIRES

1. Route Control wires towards the dash area to a switch panel (user-supplied).
2. Connect the required wires to the switch panel.

WARNING MODE

Activate Warning Mode by applying +VDC to **WHITE** wire. There is a list of built-in flash patterns to choose from. While in Warning Mode, tap +VDC to **YELLOW** wire:

- Once for next pattern.
- Quickly 3 times for FP#0.

FP#	FLASH PATTERN		
0	Kit Scan (split)	13	Single H/L (split)
1	Outside-In Single	14	Single (all)
2	Outside-In Ultra	15	Double (all)
3	Side-by-Side Single	16	Quad (all)
4	Side-by-Side Ultra	17	Quint (all)
5	Random	18	Mega (all)
6	Single (split)	19	Ultra (all)
7	Double (split)	20	Single-Quad (all)
8	Quad (split)	21	Single H/L (all)
9	Quint (split)	22	Single Cross
10	Mega (split)	23	Ultra Cross
11	Ultra (split)	24	Rotator1
12	Single-Quad (split)	25	Rotator2

DIM MODE

The Lightbar can be activated in DIM Mode by applying +12VDC to **YELLOW** wire.