

WORK LAMP *Manual*

OPERATION

RED wire: To +VDC

BLACK wire: To Chassis Ground (-)

INSTALLATION

