WORK LAMP Manual

OPERATION

RED wire: To + VDC

BLACK wire: To Chassis Ground (-)

INSTALLATION

