## WORK LAMP Manual

## **OPERATION**

**RED** wire: To + VDC

**BLACK** wire: To Chassis Ground (-)

## **INSTALLATION**

